

Installation Instructions

Screen for Model 85100 Window Protector

Important: Installation Instructions, Warranty Information. *Place in vehicle glove box after installation.*

GENERAL INFORMATION

CAUTION:

1. Park your vehicle on flat, horizontal surface. Apply parking brake or use wheel chocks to prevent accidental rolling.
2. To keep debris out of your eyes always wear protective eyewear.
3. Check contents of box against part list to make sure all components are included.

TOOLS REQUIRED:

1. 3/8" Socket Head
2. Electric drill
3. Clamps

Place the Screen on the Window Protector so the flat formed top of it will be located between upper tubing and 1" x 1" tubing. Sides of the Screen must be outside of the Window Protector. Press Screen against Window Protector and slide it down until top will lay flat on 1" x 1" tubing. Clamp Screen to Window Protector in this position. Apply adhesive E-6000 on the threads and under heads of screws before installation. Secure the Screen on the Window Protector using eight self-drilling, tapping screws.

PART NO.	QTY.	DESCRIPTION
3003923	1	Screen
3003926	8	Screw Self-Drill, Tap 1/4-14 x 3/4"
3004202	1	Adhesive E-6000, 1 oz
3003928	1	Instruction Sheet

FULL ONE-YEAR WARRANTY

Manufacturer will repair, or at manufacturer's discretion will replace any part of this Window Protector which proves to be defective in workmanship or material under normal use for period of one year from the date of delivery to the original purchaser. Any cost incurred in returning the product to the supplier is the responsibility of the consumer.

EXCLUSIONS

Manufacturer shall not be liable for special, incidental, or consequential damages or for damages resulting from lack of necessary maintenance, from misuse, abuse, act of God, or alteration of the product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

